

Water Filter FFUS-003



Replacement Filter for Filtrete 3US-AS01, 3US-PS01 Filters Fast FFUS-003



Filter Model FFUS-003

Function of the water filter

FFUS-003 is designed to remove sediment, chlorine, odor and bad taste.

Removing the Filter Cartridge

If you are replacing the cartridge, first remove the old one slowly. **Do not** pull down on the cartridge. A small amount of water may dr down.

CAUTION: If air has been trapped in the system, the filter cartridge may be ejected as it is removed. Use caution when removing.

IMPORTANT

To reduce the risk associated with ingestion of contaminants:

• Do not use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before and after the system.

IMPORTANT

To reduce the risk associated with property damage due to water leakage:

- Read and follow User Instructions before installation and use of this system.
- Installation and use MUST comply with all state and local plumbing codes.
- ullet Protect from freezing, remove filter cartridge when temperatures are expected to drop below 34°F (1°C)
- Do not install systems in areas where ambient temperatures may go above 110°F or below 40°F
- \bullet Do not install on hot water supply lines. The maximum operating water temperature of this filter system is 100°F (38°C)
- Do not install if water pressure exceeds 120psi. If your water pressure exceeds 80psi (552kPa), you must install a pressure limiting valve. Contact a plumbing professional if you are uncertain how to check your water pressure.

 Do not install where water hammor conditions may occur if the professional in the pressure in the pressure.
- Do not install where water hammer conditions may occur. If water hammer conditions exist you must install a water hammer arrester. Contact a plumbing professional if you are uncertain how to check for this condition.
- Where a backflow prevention device is installed on a water system, a device for controlling pressure due to thermal expansion must be installed.
- The disposable filter cartridge MUST be replaced every 6 months, at the rated capacity or sooner if a noticeable reduction in flow rate occurs.

General Installation/Operation/Maintenance Requirements

- Flush new cartridge at full flow for 3-4 gallons (approximately 6-8 minutes) to purge trapped air.
- Replace cartridge when flow becomes too slow.
- Protect from freezing by removing filter cartridge when temperatures are expected to drop below 40°F (4.4°C). Do not install system in areas where ambient temperatures may go above 100°F or below 40°F . Do not install on a hot water supply.

Performance Data Sheet

The concentration of the indicated substances in water entering the system was reduced to a concentration less than or equal to the permissible limit for water leaving the system as specified in NSF/ANSI standard 42.



Component

Tested and certified by WQA to NSF/ANSI 42 for material safety and structural integrity only. Tested and certified by WQA to NSF/ANSI 372 for lead free compliance.

Contaminant Reduction	Average Influent	NSF Specified Challenge Concentration	Avg. % Reduction	Average Product Water Concentration	Max Permissible Product Water Concentration	NSF Reduction Requirements	Test Report No.
Chlorine Taste and Odor	2.1 mg/L	2.0 mg/L ± 10%	99.06	0.06 mg/L	N/A	≥ 50%	REP.6519. 1402L.101 714.01

Capacity 2000 Gallons (7560Liters). Contaminant reduction determined by NSF testing



Filter Model FFUS-003



Materials and components tested to meet EC 1935/2004 Regulations.

For Residential Use Only

Application Guidelines/Water Supply Parameters					
Service Flow	2 gpm (7.6 lpm)				
Water Supply	Potable Water				
Water Pressure	30 -120 psi (207 – 827 kPa)				
Water Temperature	34° F - 100° F (1° C - 38° C)				

Note: While the testing was performed under standard laboratory conditions, actual performance may vary.

Installing the Filter Cartridge

- ①. Insert filter in filter head assembly. Turn filter one quarter turn to the right until it stops. When fully engaged, the top surface of the filter will be flush with the bottom of the filter head assembly.
- ②. Turn on water and open faucet to flush air from the system. Run water for a minimum of 5 minutes to flush out air. Check for leaks. Close sink faucet. The system is now ready for use.

NOTE: A newly installed water filter cartridge may cause water to spurt from the dispenser.

WARNING

To reduce the risk associated with choking:

• Do not allow children under 3 years of age to have access to small parts during the installation of this product.

Special Notices

- Installation instructions are included with the product when shipped.
- This drinking water system must be maintained according to manufacturer's instructions, including replacement of filter cartridges.
- The contaminants or other substances removed or reduced by this water treatment system are not necessarily in your water.
- Check for compliance with the applicable state and local laws and regulations.
- Note that while the testing was performed under standard laboratory conditions, actual performance may vary. Systems must be installed and operated in accordance with manufacturer's recommended procedures and guidelines.
- Installation and use MUST comply with all state and local plumbing codes. Do not install if water pressure exceeds 120psi. If you water pressure exceeds 80psi (552kPa), you should install a pressure-limiting valve. Contact a plumbing professional if you are uncertain how to check your water pressure.
- Do not install where water hammer conditions may occur. If water hammer conditions exist you must install a water hammer arrester. Contact a plumbing professional if you are uncertain how to check for this condition.
- Where a backflow prevention device is installed on a water system, a device for controlling pressure due to thermal expansion must be installed.

The FFUS-003 is compatible with the following absolute or alternate filter part numbers:

4306791 4306809 4306817 4306825 Icepure WF2800A-1

3US-AF01 3US-AS01 3US-PF01 3US-PS01



Filter Model FFUS-003

Function of the water filter

FFUS-003 is designed to remove sediment, chlorine, odor and bad taste.

Removing the Filter Cartridge

If you are replacing the cartridge, first remove the old one slowly. **Do not** pull down on the cartridge. A small amount of water may dridown.

CAUTION: If air has been trapped in the system, the filter cartridge may be ejected as it is removed. Use caution when removing.

IMPORTANT

To reduce the risk associated with ingestion of contaminants:

• Do not use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before and after the system.

IMPORTANT

To reduce the risk associated with property damage due to water leakage:

- Read and follow User Instructions before installation and use of this system.
- Installation and use MUST comply with all state and local plumbing codes.
- ullet Protect from freezing, remove filter cartridge when temperatures are expected to drop below 34°F (1°C)
- Do not install systems in areas where ambient temperatures may go above 110°F or below 40°F
- Do not install on hot water supply lines. The maximum operating water temperature of this filter system is 100°F (38°C)
- Do not install if water pressure exceeds 120psi. If your water pressure exceeds 80psi (552kPa), you must install a pressure limiting valve. Contact a plumbing professional if you are uncertain how to check your water pressure.
 Do not install where water hammer conditions may occur. If water hammer conditions exist you must install a water hammer.
- Do not install where water hammer conditions may occur. If water hammer conditions exist you must install a water hammer arrester. Contact a plumbing professional if you are uncertain how to check for this condition.
- Where a backflow prevention device is installed on a water system, a device for controlling pressure due to thermal expansion must be installed.
- The disposable filter cartridge MUST be replaced every 6 months, at the rated capacity or sooner if a noticeable reduction in flow rate occurs.

General Installation/Operation/Maintenance Requirements

- Flush new cartridge at full flow for 3-4 gallons (approximately 6-8 minutes) to purge trapped air.
- Replace cartridge when flow becomes too slow.
- Protect from freezing by removing filter cartridge when temperatures are expected to drop below 40°F (4.4°C). Do not install systems in areas where ambient temperatures may go above 100°F or below 40°F. Do not install on a hot water supply.

Performance Data Sheet

The concentration of the indicated substances in water entering the system was reduced to a concentration less than or equal to the permissible limit for water leaving the system as specified in NSF/ANSI standard 42.



Component

Tested and certified by WQA to NSF/ANSI 42 for material safety and structural integrity only. Tested and certified by WQA to NSF/ANSI 372 for lead free compliance.

Contaminant Reduction	Average Influent	NSF Specified Challenge Concentration	Avg. % Reduction	Average Product Water Concentration	Max Permissible Product Water Concentration	NSF Reduction Requirements	Test Report No.
Chlorine Taste and Odor	2.1 mg/L	2.0 mg/L ± 10%	99.06	0.06 mg/L	N/A	≥ 50%	REP.6519. 1402L.101 714.01

Capacity 2000 Gallons (7560Liters). Contaminant reduction determined by NSF testing